ASSEMBLING THE FIXTURE

ITEM #29581

1. Fasten mounting strip onto outlet box using 2 outlet box screws (see fig.2).
2. Thread 2-1/ 8" nipple into center hole of mounting strip about 4 complete turns. Lock in place with lock washer and hex nut. This nipple should extend long enough to protrude through the canopy when it is mounted. Adjust as necessary(see step9).
3. Connect two of straight arms between upper hook and lower hook to join fixture, then thread center tube into single connector.
4. Connect the other straight arm between upper hook and lower hook to join the fixture.
5. Using two pliers, twist open one link at the end of chain. Hook it to the loop and close the link. Place a piece of cloth between the pliers jaws and the chain link to prevent scratching the link finish.
6. Tighten the screw collar loop to the nipple on the mounting strip. Place the ring and canopy over the chain on the fixture. Using two pliers twist open the link at the other end of the chain . Connect the whole fixture to hook the screw collar loop on the ceiling and close the link.
7. Weave the fixture wires up through the chain links, through the screw collar loop and through the nipple in the mounting strip. Position both the outlet box supply wires and the fixture wires outside of the outlet box to facilitate connection. After connection (step8) is complete, carefully position black wire inside outlet box.
8. Connect the wires from the fixture to the power supply wires from outlet box (see fig.2).

a) Twist together white wire from the fixture with white wire from outlet box. Cover with wire connectors.

b) Twist together black wire from the fixture with black wire from outlet box. Cover with wire connectors.

c) Wrap the group wires from the fixture and the outlet box around the green ground screw located on the mounting strip. Tighten the green ground screw to the mounting strip.

9. Place the canopy all the way to the ceiling and tighten the ring onto the screw collar loop until the canopy is firmly held against the ceiling.
10. Install the bulbs (not included). Do not use greater than 60-watt the bulbs.
11. Thread the nipple into bushing located on the bottom of pan, secure with hex nut. Set the glass, Washer and secure with hex nut (Do not too tighten). Then set decorative cap and secure by tightening with finial.

NOTE: Carefully remove the fixture from the carton. Check that all parts shown in package parts 1 and 2 are included. Be careful not to misplace any of the screws or wire connectors which are needed for installing the fixture

Package parts 1

Description	No. Of Pieces
Chain	1
Screw Collar Loop	1
Canopy	1
2-1/8" Nipple	1
Outlet Box Screws	2
Mounting Strip	1
Wire Connectors	2
Green Ground Screw	1
Washer	1
Hex Nut	1
Ring	1

Package parts 2

Description	No. Of Pieces
Finial	1
Decorative Cap	1
Hex Nut	2
Nipple	1
Glass	1
Straight Arms	3
Washer	1